



**CRAFTING IDEA**

GB

# Big gnome out of kneading-cement

[WWW.RAYHER.COM](http://WWW.RAYHER.COM)



## Used items:

<b>34 212 000</b>	Creative-cement	2.3 kg
<b>33 042 00</b>	Styrofoam-egg 20 cm	1 pc
<b>38 798 000</b>	PET spray bottle	
<b>89 259 00</b>	Turntable	

## Additionally you need:

<b>34 026 00</b>	Modelling tool
<b>38 798 000</b>	PET spray bottle
<b>89 530 00</b>	Sandpaper
Paper towel	
Disposable gloves	
Container for kneading of the kneading-cement (e.g. bowl with lid)	
Stable support e.g. the lid of a plastic bucket	
Brush	
Stable support (e.g. the lid of a plastic bucket)	
Small tin as a stand for the styro-foam egg	
Small container with water	



## Instructions:

Place the Styrofoam egg on the stand and put on the disposable gloves.  
Always work without fail with gloves!

**1** Mix the kneading-cement in the ratio 9:1 (9 parts of cement / 1 part of water). This corresponds to about 255 ml of water. Stir the water slowly, gradually add it while constantly kneading, until the desired consistency is reached. Knead the mixture thoroughly.

**2** Take some cement between the palms, press it flat and coat thinly step by step the styro-foam egg.

### Beard

Pre-model some kneading-cement by hand, place it on the coated egg and stop up the joints with a finger.

### Nose

Mould a small amount of the kneading-cement by hand into a ball-shape and place it as a nose at the modelled beard.

### Cap

Mould the cap with kneading-cement and put it on a top of the egg. Then model the pointed end of the cap and attach it laterally.

### Feet

Model with the kneading-cement two equally large, elongated ovals and place them on a pad. Then put the dwarf's body onto them and stop up the joints.

### Hint

The cement mixture should be smooth. If the cement is cracky during kneading, just sprinkle it with some water. You can work out on the joints with a lightly moistened brush.

**3** Now you can prepare some fine decorations by using the modelling tool as for example the nostrils, the beard structure, etc.

**4** Let it dry at least for 1 day.

**5** The gnome can optionally be painted.

**6** The entire drying period lasts for several days. After about 21 days the object is weatherproof.

# Rayher.

**WWW.RAYHER.COM**

© 2016, Rayher Hobby GmbH

You will find material specifications and instructions on our homepage.