



**CRAFTING IDEA**

GB

# Fretsaw work Titmouse birdhouse



## Used items:

<b>62 913 505</b>	Plywood board with garden decoration template <sup>1</sup> set	
<b>35 023 390</b>	Glaze varnish, lagoon	1/20 bottle
<b>38 867 389</b>	Chalky Finish, cerulean	1/50 can
	or	
<b>35 023 212</b>	Glaze varnish, coral	1/20 bottle
<b>38 867 222</b>	Chalky Finish, rust	1/50 can
<b>38 363 00</b>	Stencil typeface 2, 30 × 30 cm	1 piece
<b>89 476 00</b>	Sandpaper set, assorted	1/3 sheet
<b>24 031 00</b>	Plug-in wire, annealed, 30 cm, 0.8 mm	4 cm + 26 cm

## Additionally you need:

<b>69 218 000</b>	Fretsaw set incl. gimlet hand drill
<b>38 241 00</b>	Painting sponge
<b>37 130 00</b>	Fan brush, pure white bristle, # 4, short handle
<b>37 304 00</b>	Stencilling brush
<b>89 341 00</b>	Flat nose pliers for jewellery

wide sellotape, pencil, ruler



## Instructions:

- 1 Transfer the template sheet "Meisenhaus" ("Titmouse birdhouse") with a pencil, ruler and transfer paper onto the plywood board. Screw the fretsaw board with a clamp onto the working table according to the instructions and clamp the scroll fretsaw blade into the fretsaw. Saw the titmouse birdhouse out of the plywood board along the recorded lines.
- 2 For the circle, in order to be able to hang up a titmouse fat ball later, pre-drill a hole with the gimlet hand drill, through which you clamp the scroll fretsaw blade again. Then saw out the circle along the recorded line.
- 3 Unclamp the scroll fretsaw blade and drill out the two spots for the wire by means of the gimlet hand drill. Sand the sawn titmouse birdhouse and the circle smoothly with sandpaper.
- 4 Now apply the glaze varnish in the desired colour on both sides with the painting sponge. Then let it dry well out.
- 5 Then use the fan paintbrush to apply the strong, matching Chalky Finish colour shade (with little paint on the paintbrush). Always wipe in the same direction. Let it dry well out.
- 6 Glue the chosen number, taken from the stencil typeface 2, onto the plywood board by means of the sellotape and apply the Chalky Finish paint with the stencilling brush.
- 7 Use the flat nose pliers to cut off about 4 cm of the plug-in wire, bend a hook and put it in the pre-drilled hole to fasten the titmouse fat ball. With the remaining wire, bend the suspension for the branch on the tree that you hook then onto the other pre-drilled hole.

# Rayher.

[WWW.RAYHER.COM](http://WWW.RAYHER.COM)

© 2019, Rayher Hobby GmbH

You will find material specifications and instructions on our homepage.