



**HANDICRAFT TIP**

GB

Tick-tock.  
Memories in which time tends  
to stand still.



## Used items:

<b>69 239 505</b>	Round wooden board, FSC, 25 cm ø, natural	1 piece
<b>38 867 102</b>	Chalky Finish, white	1/15 can
<b>38 867 574</b>	Chalky Finish, ebony	1/50 can
<b>38 880 000</b>	Transfer-Medium	1/15 can
<b>69 247 505</b>	Wooden numbers, FSC Mix Credit, natural	1 bag
<b>69 242 576</b>	Clock hands "Classic", black	1 piece
<b>69 237 000</b>	Quartz clockwork, 7.6 mm ø	1 piece
<b>33 487 000</b>	Klebfix-Pen adhesive	1/30 bottle

## Additionally you need:

<b>37 080 000</b>	Paintbrush set Hobby Kreativ, FSC 100 %	1 piece
<b>38 241 00</b>	Painting sponge	1 piece
<b>89 378 00</b>	Craft scissors	1 piece

compass, pencil, kitchen cloth, 1 AA battery (1.5 V)



## Instruction:

**1** Paint the entire surface of the raw wood board with the white Chalky Finish paint and let the paint dry well out.

**2** Print the desired motif as a mirror image on a DIN A4 copy paper with a laser printer. Draw a circle (with a diameter of approx. 18.5 cm) by means of the compass and cut out the motif circularly as accurate as possible with the scissors.

**3** Put the photo in the middle of the primed board and trace carefully the edge with the pencil.

**4** Firstly, paint richly by quick brush strokes the inner surface area of the wooden board with the large synthetic flat paintbrush and then the front side of the paper printout with the transfer-medium. **Important:** Do not spread the transfer-medium over the rear side of the printout, otherwise the paper can no longer be removed!

**5** Put immediately the printout face down onto the still wet transfer-medium and smooth it down with a firm pressure by hand. Excess medium at the edge can be removed with a kitchen cloth, for example.

**6** Paint the wooden numbers with the small synthetic paintbrush and the ebony Chalky Finish paint.

**7** After 8 hours drying time, moisten the paper with the painting sponge and rub off carefully the paper layers with your fingers.

**TIP:** It is recommended to work in stages. Allow to dry out between rubbing processes and then repeat it until all paper layers are removed.

**8** Mount the clock hands and the clockwork incl. battery, and stick the wooden numbers onto the white edge of the board by means of the Klebfix-Pen adhesive.

*Rayher.*

[WWW.RAYHER.COM](http://WWW.RAYHER.COM)

You will find material specifications and instructions on our homepage.

