



CRAFTING IDEA

GB

Vase out of kneading-cement

WWW.RAYHER.COM



Used items:

34 212 000	Creative kneading-cement	1.2 kg
81 283 22	Mirror-foil, silver	
33 384 00	Glue for foil	

Additionally you need:

Long balloon
Container for kneading of the kneading-cement (e.g. bowl with lid)
Disposable gloves
Stable support e.g. the lid of a plastic bucket
PET spray bottle (item 38 798 000)
Cling film
Brush
Small container with water
Container as a stand for drying (e.g. ceramic pot)

Instructions:

- 1 Blow up the balloon and prepare a piece of the cling film in the appropriate size.
For the remaining steps, always wear plastic gloves!
 - 2 Mix the creative kneading-cement (1.2 kg) with water in the ratio 9:1 (9 parts of cement : 1 part of water). This corresponds to about 130 ml. Stir the water slowly, gradually add it while constantly kneading. Knead the crumbly mixture with damp disposable gloves (if necessary, moisten several times) until the desired consistency is achieved.
- Hint** You can mix also, quickly and easily, the kneading-cement in a sealable container. Here also add the water gradually by stirring it constantly, then close the container and shake it well. That way there is less dust and the parts intermix perfectly. Knead more afterwards the crumbly mixture with wet disposable gloves (if necessary, moisten several times) until the mixture is malleable.
- 3 Take some cement between the palms, press it flat and coat that way about 2/3 of the balloon. You can get great effects, when you do not quite straighten the closing, but somewhat leave it uneven, "pointed".



- 4 Place the coated balloon on the cling film and roll it up. The cement-mixture can now be modelled with uniform strokes by hands until the surface is even and smooth. If the cement is too dry for modelling, moisten it lightly with water from a spray bottle.
- 5 For the drying, place for example a ceramic pot and fix it well, so that the cement-vase is laid out below. That way your vase gets automatically a straight, secured socle.
- 6 Let it dry at least for 1 day. Remove the balloon. The entire drying period lasts for several days. After about 21 days the object is weatherproof.
- 7 Conjure up the glossy effects by decorating, for example, the border of the vase with a sophisticated mirror-foil. Therefore, spread the glue for foil onto the border of the vase by using a brush and let it dry clearly (it lasts at least 1 hour). Then decorate it with the mirror-foil according to the package instructions.

Rayher.

WWW.RAYHER.COM

© 2016, Rayher Hobby GmbH

You will find material specifications and instructions on our homepage.