



**CRAFTING IDEA**

GB

Wooden tray  
"Love, Live..."

[WWW.RAYHER.COM](http://WWW.RAYHER.COM)



## Used items:

<b>62 061 00</b>	Wooden tray	1 piece
<b>38 867 102</b>	Chalky Finish paint, white	1/25 can
<b>38 867 266</b>	Chalky Finish paint, salmon pink	1/30 can
<b>38 867 304</b>	Chalky Finish paint, blackberry	1/20 can
<b>38 870 702</b>	Cream wax	1/10 can
<b>38 880 000</b>	Transfer-medium	1/20 can
<b>37 103 00</b>	Brush	1 piece
<b>38 241 00</b>	Sponge for painting	1 piece



## Instructions:

**1** Paint in full covering the bottom of wooden tray with the white paint Chalky Finish, the side parts with the blackberry paint Chalky Finish and the handle cutouts with the salmon pink paint Chalky Finish. Let them dry.

**2** Print out a picture and different words or writings of your choice and cut them out. Hint: print the writings always back-to-front!

**3** Place the prints on the white painted surface of the tray and mark the sections with a pencil. The painted surfaces should be dried out, clean, dust and grease free.

**4** Apply transfer-medium generously onto the bottom surface of the tray and the frontside of the laser printouts. Place the pictures and writings only with the frontside downwards on the surfaces marked with pencil and paint them carefully and evenly. Remove the excess of the medium with a cloth.

**5** After 8 hours drying time, you can moisten the paper with a sponge and gently rub off the paper layer with your fingers or the sponge for painting.

### Hint

It is advisable to work in stages. Between the rubbing processes, allow the whole thing to dry repeatedly and repeat the process until the paper layer is gone.

**6** Let it dry.

**7** Mix afterwards a little bit of the white paint Chalky Finish with the transparent cream wax (1:1) and wipe this mixture using the sponge for painting over the upper edge of the tray. When all this has dried out, you can seal the entire tray with the transparent cream wax.

# Rayher.

[WWW.RAYHER.COM](http://WWW.RAYHER.COM)

© 2016, Rayher Hobby GmbH

You will find material specifications and instructions on our homepage.